

APPLICATION NOTE

No. 1

1/7/08

Cannot Change Mode

Chatillon DF Series gages have the capability of storing readings for the statistical functions available on the DFE, E-DFE and DFS series gages. When 1 or more readings are stored, the mode change function is locked so that the statistical calculations are performed on data collected in the same mode.

To change the gage Mode all stored data must be cleared. Stored data can be cleared as follows:

1. Press the key (**F3**) under displayed "More"
2. Press the *i* key
3. Press the center key (**F2**) under displayed "Clear"
4. Press the **Enter** key

Continue with steps 3 and 4 until the display shows "0 of 0 data stored". You can now press **Home** key and change modes.