

Application Note

No.14

By: KRD

Inverting Display on Chatillon DF Series Gages

Chatillon series gages have a display inversion feature that allows the user to rotate the characters in the display window 180° so that the gage can be used in different orientations.

Inverting Normal Display Orientation 180°

- Press and release the Home Key
- Press and release F2 key (center under window)
- Press and release F1 Key (left under window)

Note that F1, F2 and F3 keys are identified from **left to right** when the gage is held as shown.



Returning to Normal Display Orientation

- Press and release the Home key
- Press and release F2 key (center under window)
- Press and release F1 Key (right under window)

Note that F1, F2 and F3 keys are identified from **right to left** when the gage is held as shown.

